


LUMEA 600




1




Opening : Unscrew the two screws (b) that holds the door (a) using a Cruciform screwdriver.

2

Wiring : Remove the upper body door/reflector/lamp/equipment (c). Connect the equipment (d) by following the instructions supplied by the attached wiring sheet.




3



Closing : Put back the door (a) and screw back the two screws (b) with a Cruciform screwdriver.


Pay attention to the cables while putting the upper body back.

LUMEA 600**MAINTENANCE****Change of lamp and equipment :**

Open the door (a) by unscrewing the two screws (b), change the lamp (g) or the equipment (d) and close back the door (a).

Maintenance :

Clean the outside and the inside of the glass (h), clean the reflector (d).

TECHNICAL CHARACTERISTICS**Overall sizes :**

Dimensions	A	B	C
LUMEA	250	620	150

Normal operating position :

vertical

Characteristics :

Weight : 6,5 Kg

CSX: 0,02 m²

Frequency : 50 Hz